



User Manual

Cartridge Replay Button Function Button TET Screen Device

PRODUCT STRUCTURE

SPECIFICATIONS

| Size: | 114.5*25*14.3mm |
|-----------------|------------------|
| Capacity: | 2 ml |
| Screen: | 0.56 inch TFT |
| Output Voltage: | 3.2-4.2V |
| Battery Type: | Built-in 1300mAh |
| Charging: | Type-C 5V/2A |

ANTI-BURN

When paired with XLIM stainless steel coil cartridges, the XLIM PRO 2 DNA version is equipped with a function to prevent the cartridge from dry burning when there is no e-liquid or insufficient e-liquid.

FLAVOR REPLAY

During the vaping process with the XLIM stainless steel coil cartridge, if you find the taste of the last puff saitslying, you can click the REPLAY button. The device will automatically follow the output curve of the last puff to ensure a consistent flavor experience.

GUIDANCE

1. JUICE FILLING





TIPS

After filling the e-juice into a new cartridge, please wait for at least 5~8 minutes before vaping to avoid dry burning.

After filling the juice, please close as soon as possible to avoid leaking.

2. VAPING

Auto-draw to vape

3 TURN ON/OFF

Press the replay button and funtion button at the same time for 2s The device will automatically power off after 1.5 days of non-use to conserve battery life.

4. OPERATING GUIDELINES

Long press the replay button for 2s

5. CHANGE LIGHTS

Press the funtion button 2 times in 1.5s

6. CHANGE POWER

Press the funtion button 3 times in 2s

7. LOCK/UNLOCK THE BUTTON FIRE

Press the funtion button 4 times in 2s

8. CHANGE LANGUANGE

Press the funtion button 6 times in 2.5s

9. RESET PUFFS

Press the funtion button 7 times in 2.5s

ATTENTION

- * Please keep away from inflammable and explosive materials to avoid injury.
- * Please don't leave the device unattended while charging.
- * Please use OXVA brand components and accessories to avoid device damage or health problems.

WARRANTY POLICY

Thank you for purchasing OXVA

products. OXVA will fulfill the following terms and conditions in order to offer the original buyer with repair or replacement under warranty:

- 1 The warranty covers defects in materials or workmanship under normal use for 90 days from the purchase date. The warranty covers the repair or replacement of any damaged parts.
- 2. This warranty may be disqualified as a result of the following circumstances:
- * The customer does not give this warranty card or the original receipt for purchase. * Merchandise failure or damage is caused
- by improper use or unauthorized adjustments. * Merchandise failure or damage caused by extreme force or impact, as well as

operating conditions that are not

- recommended.See the user handbook for details. * Merchandise failure or damage caused by exposure to water or other conducting
- * Merchandise failure or damage caused by using non-OXVA brand accessories.

liquids.

3. This warranty does not cover personal or consumable items like coil heads. USB cables, and mouthpieces.

For more information please visit our website at www.oxva.com Or email us at support@oxva.com

PURCHASE INFORMATION

Product Model:

Date of Purchase (Based on the date from receipt of purchase):

Store Information:

Store Name: Phone: ___ Store Address: Country:

Customer Information:

Customer Name:

Customer Address:

Country:

Post Code: ___





